

SERVICE SINK FAUCET ADAPTER KIT

#81911



Fast, Easy Installation!

Use existing T&S, American Standard, CHG, and Fiat unions on sink to convert to new Zurn or Chicago Back Mount Faucets. No need to remove the sink from the wall.



STEP 1: It is not necessary to remove the sink from the wall. Just locate the connecting nuts.



STEP 2: Next, remove the old control valve body by unthreading the nut.



STEP 3: Place the new washer into the fitting and thread in the Zurn AquaSpec adapter.



STEP 4: Then thread your new Zurn faucet body onto the AquaSpec adapter and tighten. (Discard supply arms supplied with new faucet.)